


USB Drivers for KETTLER devices with USB connection for OS Windows 2000/XP/Vista

1. Do **n o t** connect your device to the PC.
2. Open folder KETTLER USB driver
3. Launch the file: CP210x_VCP_Win2K_XP_S2K3.exe
4. If you now click "Install", the default installation path is used.
If you click the "Change Install Location" button, you can choose a different installation path.
5. If driver detected during installation which have to be removed confirm with 'Yes'.
6. After installation the driver you have to reboot the PC or notebook.
7. Connect the KETTLER unit with the PC or notebook.
For this, you need a USB cable (A plug to B plug)
8. The installation of the USB drivers takes place automatically.
9. Once the driver is successfully installed, the device manager will have the new entries:
CP210x USB to UART Bridge Controller
CP210x USB Composite Device



10. The drivers could be deleted with "Change or Remove Programs" under Settings > Control Panel > Add/Remove Programs.



Your KETTLER Team